

# Bravura

## Installation Guide -All Telluride 692/695/696 Entrysets-Single Cylinder Deadbolts

<p><b>1. Door Prep</b></p>	<p><b>2. Install Latch</b></p>	<p><b>3. Install Spindle</b></p>	<p><b>4. Exterior</b></p>
<p><b>5. Interior Mounting Plate</b></p>	<p><b>6. Interior Trim Installation</b></p>	<p><b>7. Door Jamb Prep</b></p>	